

# Device Usage Guide



Display Screen

Power key

Press **5s** to **turn on** the device.

Press **5s** to **turn off** the device.

Press **10s** for **factory reset**.

Reset/LED

Crashes and other serious abnormalities can be restored by pressing Reset Key.

Reset Key is also the charging indicator.

When device is **turned off**, the light turns **RED** when the battery is charging.

When device is **turned off**, the light **turns off** when the battery is fully charged.

When device is **turned on**, the light turns **RED** when the battery is charging.

When device is **turned on**, the light turns **GREEN** when the battery is fully charged.

Micro USB  
(small USB port)

Power input, for charging the device.

Type A USB  
(large USB port)

Power output for charging external devices as a power-bank

